



# **DRI-ONE Flame Retardant**

Office: (480) 964-0200  
E-mail: [drione.fr@gmail.com](mailto:drione.fr@gmail.com)  
[www.DRI-ONE.com](http://www.DRI-ONE.com)

---

## **SPECIAL FINISHING INSTRUCTIONS FOR WOOD**

**Final finishing of wood is to be done after DRI-ONE has thoroughly dried. Water base paints may be applied under most conditions, since the finished surface is to some extent penetrable.**

**Final finishes, sealers, primers and undercoats must be applied on thoroughly dry wood to eliminate entrapment of moisture under the finish. Failure to allow sufficient drying time will result in lifting or blanching of such finishes as enamel, varnish, lacquer and other synthetic finishes. The finish could also be sticky to the touch.**

**DRI-ONE Flame Retardant is not effective when applied on wood that has been previously sealed, painted or finished. Intumescent finishes are recommended in this case.**

**COVERAGE: 200 square feet per gallon on wood with flat surfaces; 100 square feet per gallon on wood shakes or other uneven surfaces.**

**Please contact Desert Research in case there are any questions. We will be pleased to assist you.**

### **CERTIFICATION**

**California Administrative Code, Title 19  
NFPA 701**

**Steiner Tunnel Test A.S.T.M. E 84  
Similar NFPA No. 225, ANSI 2.5, UBC No. 42-1, UL No. 723**